



Hose Removal Plier

AET-00587




Hose Removal Plier



Features :

- Easily disconnects hoses by gripping firmly the tubes/lines.
- Jaw for 3/16", 1/4" and 3/8" tubes and lines.
- Especially suitable for hoses connected to tubes or lines with smooth surface, where exercising pushing force is not possible.
- Pointed jaw tip allows access to confined spaces.
- Special locking design enhances secure gripping.



Instructions:

1. Remove hose clamp on the hose to be disconnected.
Insert the jaw tip into the place where hose and tube or line is connected.
2. Choose a suitable sized groove on jaw tip and grip the tube or line.
3. Move the jaw lock downward and make sure the jaw is securely locked
4. Disconnect the hose by pushing the two parts of the pliers towards each other (Fig.1 and Fig.2).

Other instruction images are as follows :

Fig. 3 Works on vacuum line on intake manifold

Fig. 4 Works on idle valve near the coolant hose to engine

Fig. 5 Works on brake booster vacuum line near firewall

Material	CrMo 4130
Hardness	HRC 43 - 47
Length	202 mm / 7.95 "
Width	94 mm / 3.70 "



AIRPRO INDUSTRY CORP.

6F-2 No.158 Kancheng Rd., Panchiao District, New Taipei City, Taiwan 22061

E-mail: sales@airprotool.com / sales@airprowu.com

Tel No : 886-2-29504785 Fax No : 886-2-89533145

www.airprotool.com Skype : airprotool

